Deep Fat Fryer

Service
Service
Service

HD 6100/A
HD 6101/A



Domestic Appliances and Personal Care

Service Manual

PRODUCT INFORMATION

Voltage	:	220-240V
Power consumption	:	2000 W
Frequency	:	50-60 Hz
Coloursetting	:	ivory with orange parts
HD 6100	:	Deep fat fryer
HD 6101	:	Deep fat fryer, lid with filter and locking knob.

MSH coding
8826 100 00000
8826 101 00000



SERVICE INFORMATION

Thermal fuse cut-off temp.	:	226°C
Oil temperature	:	185-210°C

REPAIR INSTRUCTIONS

To open the appliance use shall be made of a Torx T20 screwdriver to unscrew A. This screwdriver is available under code 4822 395 50458.

Published by Philips Domestic Appliances and Personal Care Printed in The Netherlands ©Copyright reserved Subject to modification

4822 729 21734
96/12

PCS 87 932

PHILIPS

HD 6100/A
HD 6101/A



1	4822 442 00758	Lid complete	ivory	for HD 6100
-	4822 442 00759	Lid complete	ivory	for HD 6101
2	4822 480 50541	Filter		for HD 6101
3	4822 498 10632	Grip	orange	for HD 6101
5	4822 458 10451	Basket with grip 4		for HD 6100
-	4822 458 10452	Basket		for HD 6101
6	not available			
7	4822 252 20336	Fuse unit	226°C	
8	4822 134 41226	Signal lamp	220-250V	
9	4822 381 11644	Lens	red	
10	4822 282 20288	Thermostat	220-240V	
11	4822 410 10984	Thermostatknob	orange	
12	4822 466 62669	Insulating rim		
13	4822 464 10256	Base	ivory	
14	4822 462 41294	Foot		